

INSTRUCTION MANUAL YARD GUARD BUG VAC

Warranty

Our goods come with guarantees that cannot be excluded under the Australian Consumer law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The product is warranted for 1 year from the date of original purchase.

The provision of this warranty shall not apply to any product which has been subject to abuse or misuse, neglect or accident. Nor does the warranty apply to any product that has within the warranty period been used for a purpose for which the product has not been designed or which has been repaired or altered in such a way to adversely affect its performance and reliability. Service by an unauthorized source may void the warranty.

The Kelly Company Pty Ltd neither assumes or authorizes any person to assume responsibility for damages due to accident, abuse, lack of responsible care, or the fixing of any unauthorized attachment or subjecting the product to any but 240-volt power.

Complete the following proof of purchase information and retain your store receipt/ and credit card receipt as proof of purchase, this will be required when claiming under warranty.

Date of purchase: _____

Retailer: _____

Warranty claim

1. Return BV1 in original box or re-pack securely in a new box. Please include a letter with return address, written details of product failure and proof of purchase.
2. Contact The Kelly Company Pty Ltd for return freight details on 1800 677 982 or email sales@kellycompany.com.au.

Copyright© The material used for the production of this instruction manual including text, graphics and layout are owned by The Kelly Company Pty Ltd and protected by copyright under the laws of Australia.

Trademark™ This product and packaging includes registered trade marks and trademarks which are the subject of pending applications by The Kelly Company Pty Ltd and are protected by trade mark laws of Australia.

INSTRUCTION MANUAL

Yard Guard Bug Vac Flying insect trap



Need warranty or service?

*Free call our customer service department on 1800 677 981
before returning this product to the retailer*

Product: Yard Guard Bug Vac

Model: BV1

Category Number: 71800

Contact: The Kelly Company

2 Bonz Place, Seven Hills NSW 2147

Customer service: sales@kellycompany.com.au

Visit us online: www.bugzapperlamps.com.au

INSTRUCTION MANUAL YARD GUARD BUG VAC

IMPORTANT SAFETY INSTRUCTIONS – retain and keep in a safe place.

- All warnings on the appliance and in the instruction, manual should be adhered to.
- This product should not be used near water, for example over a pond, bathtub, kitchen sink or above a swimming pool.
- Do not modify, paint or change the unit in any way.
- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely.
- Young children should be supervised to ensure they do not play with the appliance.
- The appliance should be situated away from heat sources such as radiators, stoves and other appliances which produce heat.
- The appliance should be powered only as described in these instructions or as marked on the appliance.
- The appliance should be cleaned only as recommended in these instructions and in accordance with the water and moisture warning stated in this manual.
- Do not submerge the main body of the BV1 in water (tray excepted).
- Damage requiring service. Only service by a qualified service technician when:
 - Heavy objects have fallen on the appliance.
 - The appliance has been dropped or the body of the BV1 has been damaged
 - The appliance does not operate normally or shows a marked change in operation.
 - Supply cord is damaged.

Globe replacement

Buy globes online, view replacement instructions & FAQ: www.bugzapperlamps.com.au
 Service department: 1800 677 982

Trouble shooting

Problem	Possible Reason	Correction
UV globe does not light	Unit not plugged into live power point	Check if fan is working, if not, check power socket lead and plug.
	Globe has burned out	Call for a replacement
	Globe is not installed correctly	Check online for replacement instructions or call service department
No down draft of air	Unit not plugged into live power point	Check if globe is working and if not, check power point lead and plug.
	Fan has failed	Call service department
No insects in the drawer	Detergent has not been added to the drawer	Add a few drops of detergent to water

INSTRUCTION MANUAL YARD GUARD BUG VAC

Please read the manual carefully, failure to operate the BV1 in accordance with the instructions in this manual may cause damage to the unit.

Bug Vac utilises a highly effective and efficient attract, kill and dispose process.


Attract: flying insects to the front opening of the unit by a purpose designed low wattage ultra violet black light (rated 6000 hours) and an inbuilt light reflector.

Kill: as insects are attracted to the light, a lethal down draft of air from the integrated fan propels them into a reservoir of water containing a few drops of a surface tension reducing surfactant (dish washing detergent) downing them quickly.

Dispose: the dead insects are easily disposed of by emptying the water tray in the garbage.

Specification

- Operation: Input 230-240 Volts 50 Hz
 Operational diagram (right)
- Lamp: UV Black light 8 watts, cat number 71450
- Fan: 32-watt integrated fan.
- Rated: IPX4 Weatherproof.
 Bug Vac complies with SAA safety standards



UV Light

The UV black light is long wave and safe to use at home. The intensity of the lamp reduces with use. To maintain maximum attraction of flying insects, replace the globe every 24 months, also replace if the globe is dull, flickering, black on the ends, or fails to illuminate.

Operation

Bug Vac delivers an effective dust to dawn solution for the control of flying insect pests. Its modern stylised design makes it suitable for use inside or outside.

Positioning: position Bug Vac as far away from your entertaining area or the centre of activity and facing the area you want to protect. When used outdoors, Bug Vac covers an area of up to ½ acre.

Mounting: Bug Vac can be used as a free-standing unit on a cupboard or it can be mounted on the side of a building, garage, fence or even a tree. A convenient metal mounting bracket is supplied with the unit. It is recommended that Bug Vac is mounted approximately 1.8 metres from ground level

Slide the water tray should out after Bug Vac has been installed, fill with water (fill drawer approximately ¾ full), add a few drops of detergent to break the water surface tension which will allow insects to be pushed into the water. Connect to mains power and allow to operate 24/7 or dusk to dawn.

Cleaning: Clean the lens and reflector regularly to ensure UV light is always bright. Empty the drawer when it is filled with insects, refill with water adding a few drops of detergent.

