

INSTRUCTION MANUAL Insect Control Station

Specification

Globe: UV Black light 6 watts
Cat number 71462
Recharger: 500Ma 7.5V

Warranty

Our goods come with guarantees that cannot be excluded under the Australian Consumer law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The product is warranted for 1 year from the date of original purchase.

The provision of this warranty shall not apply to any product which has been subject to abuse or misuse, neglect or accident. Nor does the warranty apply to any product that has within the warranty period been used for a purpose for which the product has not been designed or which has been repaired or altered in such a way to adversely affect its performance and reliability. Service by an unauthorized source may void the warranty.

The Kelly Company Pty Ltd neither assumes or authorizes any person to assume responsibility for damages due to accident, abuse, lack of responsible care, or the fixing of any unauthorized attachment or subjecting the product to any but 240-volt power.

Complete the following proof of purchase information and retain your store receipt/ and credit card receipt as proof of purchase, this will be required when claiming under warranty.

Date of purchase: _____

Retailer: _____

Warranty claim

1. Return Insect Control Station in original box or re-pack securely in a new box. Please include a letter with return address, written details of product failure and proof of purchase.
2. Contact The Kelly Company Pty Ltd for return freight details on 1800 677 982 or email sales@kellycompany.com.au.

Failure to operate the product in accordance with the instructions may cause damage to the unit and void warranty.

INSTRUCTION MANUAL

Stinger Insect Control Station Flying insect trap & Pest Repeller



Need warranty or service?

*Free call our customer service department on 1800 677 981
before returning this product to the retailer*

Product: Stinger Insect Control Station

Model: ICS955

Category Number: 71968

Contact: The Kelly Company
2 Bonz Place, Seven Hills NSW 2147
Customer service: sales@kellycompany.com.au
Visit us online: www.bugzapperlamps.com.au

INSTRUCTION MANUAL Insect Control Station

IMPORTANT SAFETY INSTRUCTIONS – retain and keep in a safe place.

- All warnings on the appliance and in the instruction, manual should be adhered to.
- Suitable for indoor use only. Not suitable for use in barns, stables and similar locations.
- Do not submerge the Insect Control Station in water.
- Do not use where flammable vapour or explosive dust may exist
- Do not modify, paint or change the unit in any way.
- Keep out of reach of young children.
- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely.
- Young children should be supervised to ensure they do not play with the appliance.
- The appliance should be situated away from heat sources such as radiators, stoves and other appliances which produce heat.
- The appliance should be powered only as described in these instructions or as marked on the appliance.
- The appliance should be cleaned only as recommended in these instructions and in accordance with the water and moisture warning stated in this manual.
- Lead acid battery should only be replaced by a qualified service technician.
- Damage requiring service. Only service by a qualified service technician when:
 - Heavy objects have fallen on the appliance.
 - The appliance has been dropped or the body has been damaged
 - Supply cord to recharger is damaged.

Globe replacement

Buy globes and replacement mats online, view replacement instructions & FAQ: www.bugzapperlamps.com.au or contact our service department: 1800 677 982

Trouble shooting

Problem	Possible Reason	Correction
Globe does not light up	Battery needs to be charged	Refer section on charging in this manual
	Globe is faulty	Contact customer service for a new globe or buy online
	Battery is faulty	Contact customer service
Battery is fully charged but globe doesn't light up	Globe needs replacing	Contact customer service for a new globe or buy online
	Globe is not correctly installed	Check replacement instructions online or call customer service
Globe only lights up for a few hours after full charge	Battery could be faulty	Contact customer service

INSTRUCTION MANUAL Insect Control Station

Please read the manual carefully, failure to operate the Stinger Insect Control Station in accordance with the instructions in this manual may cause damage to the unit.

Your portable/rechargeable Insect Control Station (ICS995) uses safe ultraviolet light and proven adhesive entrapment mats to effectively attract, capture and kill flying insects. It also incorporates ultrasonic sound waves to repel crawling pests from your home.

Charging the Home Insect Control Station

Although the trap may come partially charged, it is recommended that the battery be fully charged before use. Only use the recharger 7.5V AC-DC supplied with this product.

- 1) Turn both flying insect and crawling insect switches into OFF position
- 2) Plug recharger into port and charge for between 8-10 hours
- 3) To check battery status, remove charging port and turn the flying insect and crawling insect switches into ON, battery indicator will illuminate green.

Warning: for the purposes of recharging the battery, use only the detachable supply unit provided with this appliance.

Mat installation:

- 1) Hold mat by the tab and peel away the protective release paper to expose the yellow adhesive surface.
- 2) Ensure the yellow surface of the mat is facing the front of the Insect Control Station, and carefully slide the mat through the access slot avoiding contact with the UV globe.
- 3) If the mat sticks to the globe, pull mat sideways and repeat above step.
- 4) Check mat regularly to review insect loading- replace after 6 weeks or sooner if required.

Crawling Ultrasonic Pest Repeller

The ICS emits ultrasonic sound waves that repel rats, mice, ants and spiders. An amber light on the front of the trap will illuminate and flash, indicating the repeller is operational. Effective in a standard size room (approximately 5m²). Do not use near pet mice, rats or spiders.

Operation

After an 8 hour charge, the ICS UV globe should illuminate for up to 6 hours on the flying insects setting. It will not function whilst charging. To start operation, remove the adaptor from the back of the unit and select the required function or functions.

Flying insect control: Ensure adhesive mat is in place, slide flying insect switch into ON position. The green light on the front of the unit will light up (static light) and the UV globe will illuminate.
Crawling pest repeller: Slide the crawling pest switch into ON position. The amber indicator light on the front of the unit will light up and flash intermittently indicating the pest repeller is active. Operate together or independently by turning the desired function into the ON position and the other into the OFF position.

Cleaning: Replace the adhesive mat every 6 weeks or sooner if required. Once the mat is covered with insects it will no longer be an effective form of entrapment. If bugs are caught on the outer plastic cover or around the globe, use a long handed paint brush to brush them away.